

PahaQue Custom Shop, Inc

MeerKat Trailer Awning

SETUP INSTRUCTIONS



Thank you for purchasing the MeerKat Trailer Awning, another quality product built in the USA by PahaQue Custom Shop, Inc. This product will provide you with years of service, and is backed by our Lifetime Warranty against any and all defects in materials and workmanship, while our fabric carries a 3 year warranty against UV and other damage. When used and cared for properly, this product will provide many years of reliable service.

A FEW QUICK NOTES:

- **SET-UP**---Your Awning can be easily set-up in 5 minutes or less by one or two people, if you follow the basic sequence detailed below. If time allows, we would recommend that you read through these instructions in their entirety and do a practice set-up at home before heading into the wilderness. Then you can be sure all components are present & functional, and proceed through the set-up sequence at a leisurely pace to learn the most efficient techniques.
- **TAKE DOWN** --- For the take down, simply reverse the set-up sequence.
- **LONG TERM STORAGE** --- Your MeerKat Trailer Awning is more likely to be damaged by mold, mildew or bacteria during storage than by elements while set up and in use. Make sure that all food or other organic material is removed, and that your tent is thoroughly dry before packing into the stuff bag. If you have to pack up and leave the campsite while your tent is damp, set it up later at home & allow it to dry thoroughly for long-term storage.

How to install your MeerKat Trailer Awning by PahaQue

1. **Locate** the following parts included with your MeerKat Trailer Awning:
 - Awning body
 - Two fiberglass roof poles
 - 2 aluminum awning poles
 - Ground stakes - 2
2. **Unfold** Awning and locate keder cord edge of Awning. Make sure awning is right-side-up by checking that the coated (shiny) side of the Awning fabric is facing downward.
3. **Starting** at the rear of the trailer, slide the Awning keder cord into the keder rail on the passenger side of your trailer. Center the keder cord in the keder rail.
4. **Locate** the two fiberglass roof poles and assemble them. Insert both ends of the roof poles into the pole pockets in the corners of Awning body.
5. **Locate** and assemble the 2 aluminum awning poles. Note that each pole has one longer peg and one shorter peg on the ends. Insert the longer pegs into the grommets in the 2 outer corners of the awning. Stand the poles up vertically and secure with the attached guy lines and included ground stakes.

Final adjustments:

USEFUL TIPS:

- Do not store your Awning while wet for any extended period – always dry completely prior to long-term storage.
- Note that the pockets for the aluminum roof pole may need to be sealed around the seams. Use the enclosed Seam Grip® Seam Sealer.

You can register your product online by visiting www.pahaque.com, or by calling us toll-free at **1.888.700.TENT** (8368).